



Tesla Model 3

Electric Vehicle

Automatic (Electric Motor)



Remote key options

- Use phone key, key card or key fob to lock or unlock the vehicle.



Starting car

- Keyless entry vehicle; no ignition.
- Key needs to be inside vehicle.
- Place your foot on the brake and select a gear from the drive stalk on the right side of the steering wheel.



Turning the engine off

- Put vehicle into Park Gear (P) by pressing the button on the end of the drive stalk.
- Vehicle automatically powers off after being in Park for 15 minutes.



Driving Distance

- The remaining driving distance is displayed on the center console



Technology

- Blind Spot Alert – the real-time road visualisation on the touchscreen informs you if a vehicle is in your blind spot.
- Lane Assist – monitors the markers on the lane as well as surrounding objects and other vehicles.
- Traction Control – the traction control system is automatically turned on by default - an indicator will flash if the system is actively controlling brake pressure



Autopilot

- A variety of autopilot features are available, such as Autosteer, Traffic-Aware Cruise Control, Auto Lane Change, Summon, and more. See page 79 of owner manual for more information.



Indicators

- Located on the left side of steering wheel.



Lights

- Adaptive Headlights and High Beam – operates when headlights switched to AUTO position for more information see Page 52 of owner manual.



Child Safety

- Belt-based – secured using the vehicle's seat belts on the front passenger seat and back row of seats.
- ISOFIX – 2 sets of anchor bars located in the back row of seats.



Reversing Camera

- Whenever the vehicle is in Reverse, the touchscreen displays the view from the rear view camera.



How to charge your battery

- The charge port is located on the left rear side of the vehicle next to the tail light.
- The vehicle is equipped with a Mobile Connector and the adaptors needed to plug into most commonly used power outlets.
- For more information, see page 150 of the Owner's Manual.



Bluetooth Pairing

- Touch the Bluetooth icon on the top of the touch screen, and select Add New Device > Start Search. Select the device you want to pair. The touch screen will display a number, confirm it matches the number on your phone.



Heating

- Driver, front, and rear passenger seats can be heated. Climate control settings are on the bottom of the touch screen.



Snow chains

- Rear tyres only.



Anything else you need to know?

- For further information please view the owner's manual in the glove box.

Roadside Assistance	Customer relations
• 1800 996 010	• 1800 550 078
	• aushertzcustrel@hertz.com